

INTRON

INTEGRATED ELECTRONICS TECHNOLOGY PVT. LTD.

Get the best of two technologies (thin film & thick film) in one package

DESIGN YOUR OWN RESISTOR NETWORK

MAINTAIN SECURITY
AND PROTECT
YOUR DESIGN

STEP 1: Fix the number of pins in the network
from 3 to 16

STEP 2: Decide the resistors values from
 10Ω to $10M\Omega$

STEP 3: Decide the absolute tolerance and
the ratio tolerance

STEP 4: Decide the absolute TCR and the
TCR tracking

STEP 5: Draw the interconnections

